

PRISLISTA SAIA REPARATION

Artikel	Repareras	Pris SEK
PCD1.Axx		855
PCD1.B10XX		2100
PCD1.B5000-A20		912
PCD1.E1000-A10		615
PCD1.G2xx		2109
PCD1.G3XX		2839
PCD1.G5xx		3800
PCD1.M2110R1		3032
PCD1.M21xx		3819
PCD1.M2220-C15		3078

PCD2.Axx		740
PCD2.Exx		569
PCD2.F21xx		700
PCD2.F22xx		1493
PCD2.F27xx		1015
PCD2.H1xx		1139
PCD2.H2xx		1741
PCD2.H3xx		1357
PCD2.Kxx	NEJ	
PCD2.M4160		3101
PCD2.M4560		5291
PCD2.M5xx		6700
PCD2.W2xx		1242
PCD2.W31xx		1242
PCD2.W340-W380		1482
PCD2.W4xx		1334
PCD2.W525		1334
PCD2.W6xx		1710

PCD3.Axx		649
PCD3.C100-110		626
PCD3.C200		911
PCD3.E1xx-E6XX		684
PCD3.F1xx		786
PCD3.F21xx		786
PCD3.F22xx		786
PCD3.F240		1493
PCD3.F261		1493
PCD3.F270		3762
PCD3.F271		1014
PCD3.H112		1014
PCD3.H114		1378
PCD3.H150		1014
PCD3.H3xx		1425
PCD3.Kxx	NEJ	
PCD3.M2130V6		5576

PCD3.M2330A4TS		7365
PCD3.M3120		4618
PCD3.M3330		5975
PCD3.M3360		5586
PCD3.M5340		7891
PCD3.M5360		7800
PCD3.M5540		8278
PCD3.M5560		7891
PCD3.M6860		10274
PCD3.M6880		15098
PCD3.R5xx-R6xx		1998
PCD3.T665		1334
PCD3.T666		2462
PCD3.T760		1710
PCD3.W2xx		1367
PCD3.W340-W380		1561
PCD3.W4xx		1401
PCD3.W525		1401
PCD3.W600		1490
PCD3.W605		1881
PCD3.W745		1835

PCD7.D410VT5F		7754
PCD7.D410VTCF		6614
PCD7.D412VT5F		8883
PCD7.D412DTPF		6614
PCD7.D457VT5F		5667
PCD7.D457VTCF		5697
PCD7.D470WTPF		4093
PCD7.D450WTPF		3169

PCD1.F1xx		786
PCD7.Hxx	NEJ	
PCD7.Kxx	NEJ	
PCD7.Lxx	NEJ	
PCD7.Rxx	NEJ	
PCD7.Txx	NEJ	
PCD7.W600		1139
Q.NET	NEJ	
Q.PS-xx	NEJ	

Om din produkt inte finns med i detta dokument vänligen kontakta oss för mer information