

##### Television (TV) #####

A.R. Systems	0586, 0404
Accent	0067, 0586
Acec	0042
Acer	1369, 1674
Acoustic Solutions	1697, 1615
Adcom	0655
Admiral	0123, 0393, 0448, 0117, 0193, 0294
Adyson	0098, 0247, 0246
AEG	0636, 1067, 1179, 2051
Agashi	0246, 0247
AGB	0546
Agef	0117
Aim	0067, 0586, 0304
Aiwa	0731, 1934, 1946, 1938, 1945, 1535
Akai	0391, 1356, 0238, 0401, 0067, 0463
	0221, 0065, 0039, 0102, 0248, 0582
	0744, 0193, 0546, 0745, 0632, 0586
	0578, 0611, 0510, 0247, 0661, 0246
	0294, 0478, 0208, 0407, 0636, 0738
	0381, 0616, 1067, 1938, 0503, 0678
	0842, 1278, 1965, 2051, 2126, 1757
	1338, 1895, 1553, 1682
Akiba	0248, 0312, 0485, 0067, 0586, 0324
Akira	2271, 2363
Akura	1800, 1717, 1697, 1675, 1615
Alba	1067
Alkos	0065
Allorgan	0236, 0324, 0247
Allstar	0067, 0586
Ambassador	0207
Amitech	0685, 1879
Amoi	1559, 2372
Amstrad	0207, 0039, 0546, 0294, 0401, 0248
	0067, 0586, 0463, 0442, 1067, 0678
	0611, 1934, 1354, 2012, 2171
Anam National	0680
Andersson	1179, 1615, 0067
Anglo	0039, 0294
Anitech	0039, 0098, 0294, 0067, 0586, 0312
	0132
Ansonic	0400, 0067, 0586, 0039, 0698, 0404
	0193, 0322, 0132, 0441, 0289, 0277
	1467, 0042, 0458, 1934, 0134, 1698
AOC	1618, 2141, 2244
Apollo	0503
Arcam	0246, 0247
arctic	1682
Ardem	0516, 0067, 0586
Arena	0067
Aristona	0586, 0067, 0042, 0043
ART	1067
Art Mito	1615, 2171, 1697
ASA	0135, 0376, 0100, 0134, 0117, 0193
	0209
Asberg	0067, 0586, 0132
Asora	0039

Atec	1636					
Atlantic	0067,	0586,	0246,	0236,	0350,	0289
Atori	0039					
Audiosonic	0067,	0586,	0139,	0744,	0745,	0247
	0400,	0367,	0294,	0248,	0516,	0458
	2013,	2134				
Audioton	0247,	0516,	0400,	0294,	0458	
Autovox	0117,	0236,	0267,	0574,	0379,	0247
	0277					
AVP	1934,	1938				
Axxent	0039					
B&D	1247					
Baier	1354,	2269				
Bang & Olufsen	0595,	0650,	0117,	0305		
Barco	0410,	0582,	0193			
Basic Line	0404,	0067,	0193,	0698,	0586,	0039
	0248,	0312,	0247,	0485,	0369,	1067
	1698					
Bastide	0247					
Bauer	2227					
BBK	1553,	1675				
Beaumarck	0208					
Beko	0744,	0516,	0745,	0067,	0458,	0400
	0586,	0636,	0838,	1682,	2155	
Belson	0728,	0736				
Belstar	1067					
Bennett	0586,	0067				
BenQ	1592,	1745,	1553,	2244		
Beon	0067,	0586,	0448			
Best	0367,	0400,	0451			
Bestar	0067,	0586,	0400,	0404		
Bestwell	1356					
Black Diamond	1067,	0586				
Black Panther	0132					
Blackway	0312,	0248				
Blaupunkt	0584,	0225,	0221,	0565,	0230,	0357
	0358,	0478,	0485,	0200,	0066	
Blauren	0404					
Blue Sky	0067,	1067,	0744,	0517,	0698,	0745
	0655,	1682,	0654,	1939,	0586,	0248
	0312,	0485,	1964,	1934,	1938,	1698
	0838,	1393,	1769,	1946		
Bondstec	0277					
Boots	0302,	0247,	0039			
Bork	1393					
Bosch	0350,	0357				
BPL	0067,	0586,	0312			
Brand Unknown	2227					
Brandt	0655,	0139,	0267,	0226,	0228,	0317
	0365,	0598,	0501,	0373,	0590	
Brandt Electronique	0317,	0365,	0598			
Brinkmann	0067,	0586,	0698,	0549,	0448,	0516
	1698					
Brother	0294					
Bruns	0117,	0327,	0458,	0516		
BSR	0193,	0324,	0582,	0391		
BTC	0248					

Bush	1067, 1356, 2157, 1615, 2155, 1179
	0401, 1586, 1946, 1682, 1697
Cameron	1553, 0586
Canton	0248
Capsonic	0294
Carad	0640, 0067, 0586, 0698, 1067, 1698
Carrefour	0066, 0100, 0067, 0586
Cascade	0039, 0067, 0586
Casio	0067, 0586, 0193, 0379, 1934
CAT	1712
Cathay	0067, 0586
Centrum	1067
Centurion	0067, 0586
Century	0117, 0277, 0268
CGE	0104, 0114, 0336, 0448, 0277, 0582
	0400, 0193, 1934
Chimei	1696
Cimline	0039, 0265, 0248
City	0039
Clarivox	0448, 0067, 0586, 0100, 0132, 0327
Clatronic	0067, 0400, 0401, 0744, 0248, 0294
	0586, 0247, 0277, 0039, 0132, 0350
	0609, 0678, 1934, 0636, 1354
Clayton	0415, 1067
CMS	0246, 0247
Combitech	1938
Concorde	0039
Condor	0350, 0067, 0586, 0400, 0246, 0039
	0312, 0132, 0277, 0448, 0441, 0193
	0294
Conia	1717, 1675
Conrad	0067, 0586
Contec	0246, 0039, 0187, 0041, 0066, 0294
	0067, 0586
Continental Edison	0139, 0267, 0226, 0228, 0317, 0517
	0598, 0684
Cosmel	0039, 0367, 0067, 0586
CPTEC	0655, 1393
Crosley	0117, 0277, 0104, 0114, 0582, 0193
Crown	0039, 0400, 0516, 0067, 0586, 0517
	0744, 0636, 0745, 0451, 0448, 0389
	0609, 0238, 0683, 0369, 1964, 1067
	1682, 0698, 2051
Crystal	0461
CS Electronics	0444, 0246, 0248, 0277
CTC	0277
CWR-Tech	1354
Cybertron	0248
D.Boss	0067
Daas	0327
Daewoo	0664, 0691, 0529, 0654, 0404, 1939
	0067, 0586, 0039, 0246, 0248, 0247
	0481, 1167, 1932, 1938, 0910, 0895
	0728, 0744, 0736, 2067, 1406
Dainichi	0248, 0246
Dansette	0442
Dantax	0400, 0516, 1682, 1946, 0744, 0636

	1067, 0745, 1938
Daytek	1406
Daytron	0039, 0404, 0067, 0586
de Graaf	0238, 0074, 0257, 0193, 0578, 0393
Denver	0067, 0586, 0636, 0617, 1879, 2269
	1354, 2080, 2126, 2051, 1739, 2169
	2171, 2227, 2275, 1800
Desmet	0350, 0067, 0586, 0039, 0117, 0381
DiBoss	0067, 0586
Digihome	1697
Digiline	0067, 0586, 0135, 0698, 1698
Digimate	0920
Digital Device	1636
Digitek	1739
DigiX	0910
diVision	2227
Dixi	0039, 0067, 0586, 0327, 0277, 0247
	0117
DMTECH	2031, 2184, 2253
Domland	0424
Doric	0231, 0379
Dream Vision	1734, 1784
DTS	0039
Dual	0574, 0379, 0247, 0373, 0549, 1267
	0067, 0586, 0289, 0382, 0424, 0333
	0582, 0193, 1934, 1167, 0661, 1179
	1067, 2271, 1697, 1615, 1354, 0744
	2227
Dumont	0117, 0134, 0132, 0247, 0100, 0102
	1934
Dunai	0574, 0193
Durabrand	0067, 1467, 0586, 1682, 1067, 0744
Dux	0067, 0586, 0042
D-Vision	2012
Dynatron	0067, 0586, 0042
Dyon	2271
E.S.C.	0067, 0586, 0247
e:max	1354, 0636
ECG	2227, 2269, 2155, 0067, 1067
Edison-Minerva	0517
Elbe-Sharp	0546
Elekta	0039, 0067, 0586, 0294, 0312
Elfunk	1238, 1067
Elin	0246, 0067, 0586, 0135, 0134, 0578
	0391, 0478, 0379, 0193, 0039
Elite	0248, 0067, 0586, 0350
Elta	0039, 0098, 0294, 0246, 0461
Emco	0277
Emerson	0207, 0117, 0277, 0067, 0586, 0401
	0100, 0312, 0350, 0391, 0654, 1939
	0516, 0400, 0193, 0351, 1934, 0698
	1698
e-motion	1739, 2136
Epson	1320
Erison	1712
Erres	0067, 0586, 0042
Estèle	0582, 0193

Etron	0067, 0586, 0850, 0039, 0193
Eurofeel	0294, 0247, 0684
EuroLine	0067, 2080
Euroman	0246, 0294, 0067, 0586, 0247, 0451 0400
Europa	0067, 0586
Europhon	0067, 0546, 0132, 0193, 0247, 0586 0277, 0582, 0461, 0246
Evesham	1697
Excello	1067
Expert	0236, 0289, 0193
Fenner	0404, 0039
Filsai	0247
Finlux	0135, 0134, 0067, 0586, 0744, 0376 1615, 1697, 0247, 0102, 0582, 0193 0546, 0745, 0100, 0117, 0209, 0132 0441, 0661, 0522, 0510, 1586, 0659 0503, 0448, 0636, 0651, 0838, 1278
Fintec	2012
Firstline	0067, 0586, 0404, 0698, 0744, 0654 0193, 0039, 0324, 0351, 0246, 0415 0277, 0582, 1939, 0132, 0247, 0441 0574, 0379, 0268, 0102, 0265, 0238 0391, 1067, 1698, 0838, 1393, 1338
Fisher	0134, 0247, 0066, 0238, 0400, 0585 0327, 0075, 0117, 0187, 0391, 0582 0193, 0333, 0574, 0379, 0102
FNR	0132
Force	1179
Formenti	0193, 0067, 0586, 0516, 0246, 0117 0350, 0582
Formenti-Phoenix	0246, 0350, 0582
Fortress	0123, 0117
Fraba	0067, 0586, 0400
Friac	0039, 0067, 0586, 0132, 0451, 0400 0529, 0685, 0640
Frontech	0277, 0294, 0379, 0444, 0393, 0461 0478, 0247, 0039, 0193
Fujitsu	0713, 0883, 0236, 0102, 0132, 0247 0193, 0039, 0382, 0067, 0586, 0391 0289
Fujitsu General	0039, 0247, 0236, 0193
Fujitsu Siemens	1696, 1328, 1278, 0838, 2204
Funai	1847, 1424, 1067, 1696, 1625, 0698 0294, 0324, 0333, 0442, 1698, 1535 1934, 0744, 1682
Future	0067, 0586
Gaba	1067, 0067
Galaxi	0132, 0067, 0586, 0391, 0193
Galaxis	0400, 0448, 0067, 0132, 0586
Galeria	0039
GBC	0582, 0193, 0039, 0404, 0248, 0393
GE	0373, 0765
GEC	0193, 0391, 0379, 0067, 0546, 0586 0073, 0102, 0247
Geloso	0277, 0039, 0393, 0582, 0193, 0404
General Electric	0373, 0317

General Technic	0039					
Genexxa	0248, 0067, 0586, 0442, 0523, 0193					
	0039					
Gericom	1636, 1751					
GoGen	1697, 0067, 1067					
Goldfunk	0698, 1698					
Goldline	0367					
GoldStar	0067, 0039, 0400, 0320, 0407, 0247					
	0277, 0246, 0586, 0461, 0193, 0391					
	0139, 0393, 0636, 0074, 1964, 0744					
	0745, 0485					
Gooding	0517					
Goodmans	1278, 1615, 1067, 2013, 1946					
Gorenje	0400, 1615, 1697, 0451					
GPM	0248					
Graetz	0391, 0401, 0193, 0067, 0369, 0586					
Gran Prix	0678, 1226, 2227, 2363					
Grandin	1682					
Grundig	0225, 1253, 1612, 0473, 0221, 2157					
	1717, 0584, 0100, 0565, 1067, 0517					
	0067, 2037, 0736, 0267, 0586, 0617					
	0039, 0066, 0400, 0770, 1965, 1938					
	0660, 1946, 1338, 0208, 1406, 0373					
	1697, 2083, 2269, 2155, 1675, 1553					
Grunpy	0209					
H&B	0838, 2031					
Haier	2242, 2244, 2271					
Halifax	0294, 0246, 0247					
Hampton	0246, 0247					
Hanimex	0248					
Hanns.G	1643					
Hannspree	1381, 1643, 1806, 2057, 2244					
Hantarex	0039, 0067, 0586, 0132, 0546, 0268					
	2161, 0895					
Hantor	0067, 0586					
Harsper	0895					
Harwa	1226					
Hauppauge	0067, 0586					
HCM	0039, 0442, 0067, 0586, 0247, 0248					
	0448, 0312, 0294, 1226					
Hedzon	0586, 0067					
Hema	0247, 0039					
Highline	0294, 0067, 0586					
Hisense	1393, 2067, 1769					
Hit	0117					
Hitachi	1606, 2237, 1802, 1615, 0511, 0608					
	0749, 0255, 0379, 0774, 0386, 1067					
	0760, 1514, 1511, 0471, 2157, 1717					
	1697, 1255, 0664, 1075, 0503, 0593					
	0582, 0373, 2244, 0226, 0228, 0529					
	1179, 2035, 2037, 0257, 0827, 0073					
	0224, 0510, 0473, 0546, 0102, 0067					
	0074, 0586, 0139, 0393, 0578, 0208					
	1167, 0135, 0066, 0193, 0522, 0389					
	0391, 0659, 0247, 0336					
Hitachi Fujian	0138, 0255					
HMV	0117					

Höher	0744, 1586, 0895
Horizont	1647
Huanyu	0404, 0246
Hugoson	0920, 1247
Humax	1325, 1569
Hyper	0039, 0246, 0247, 0277
Hypersonic	0391
Hypson	0067, 0586, 0744, 0745, 1964, 0294 0247, 0312, 0485, 0268, 1938, 1067 0698, 1698, 0516
Hyundai	2169, 1929, 1356, 1724, 1274, 0895 1636, 0736, 1586, 1406, 2184
Iberia	0067, 0586
ICE	0294, 0067, 0401, 0039, 0586, 0248 0247, 0246
IISonic	1406
Iiyama	1247, 0920
Imperial	0067, 0193, 0400, 0104, 0114, 0586 0660, 0441, 0391, 0379, 0448, 0277 0226, 0461, 0582
Indesit	0267
Indiana	0067, 0586
InFocus	1460, 2229
Ingelen	0517, 0640, 0744, 0193, 0391
Ingo Devices	2269
Inno Hit	0039, 0102, 0067, 0586, 0248, 0320 0247, 0546, 0277, 0132, 0312, 1615
Inspira	1354, 1586
Interactive	0067, 0586, 0042, 0117, 0542, 0305 0357, 0193, 0391, 0400, 0139, 0598 0441
Interbuy	0039, 0067, 0294, 0277, 0098, 0542 0586
Internal	0067, 0586, 0654, 0529, 0404, 1939
International	0246
Intervision	0312, 0247, 0485, 0067, 0098, 0401 0407, 0549, 0478, 0516, 0400, 0424 0517, 0444, 0248, 0132, 0461, 0193 0294, 0277, 0684, 0039, 0586
Isukai	0248, 0067, 0586, 0312, 0485
ITC	0247, 0582, 0350
ITS	0067, 0401, 0248, 0312, 0294, 0246 0039, 0586
ITT	0193, 2155, 0510, 0379, 0391, 0503 0578, 0381, 0223, 0376, 0369, 0238 0616, 0209, 0574, 0640, 1553, 2087
ITT Nokia	0391, 0578, 0193, 0503, 0510, 0379 0376, 0238, 0209, 0369, 0381, 0616 0636, 0640, 0661, 0393, 0461
ITV	0294
Jay-tech	2269
JDV	2012
Jean	0066
JEC	0065
Jubilee	0586
JVC	0683, 1848, 2148, 1183, 0636, 0401 0761, 0713, 0066, 0220, 0222, 0223

	0248, 0448, 0123, 0680
Karcher	0067, 0586, 0451, 0400, 0640, 0193
	0312, 0132, 0294, 0744, 1586, 0636
	2012, 2155, 1338
Kathrein	0586, 0067, 0910
Kendo	0067, 0640, 0586, 0193, 0549, 0542
	0400, 0407, 0393, 0458, 0441, 0132
	0265, 0277, 0678, 1615, 1067, 1467
	0516, 1179, 1167
Kennedy	0193, 0236, 0582, 0465
Kennex	1067
Keydo	1732
Kingsley	0246
Kiton	0586, 0067, 0698, 1698
Kolster	0067, 0586, 0132, 0379, 0277, 0248
Konka	0067, 0586, 0401, 0744, 0448, 0248
Kontakt	0517
Korpel	0067, 0586
Kotron	0442, 0294, 1930
Koyoda	0039
Kriesler	0042
Kuba	0379, 0193
Kuba Electronic	0333, 0379, 0193
Kyoshu	0442, 0448, 0294
Kyoto	0415, 0193, 0246, 0247
LaSAT	0516, 0400
Leader	0039
Lemair	0441
Lenco	0039, 0067, 0193, 0404, 0586, 0134
	0617, 1067, 2013
Lesas	0277
Levis Austria	0067, 0586
Lexsor	1226
Leyco	0294, 0102, 0067, 0586, 0324, 0609
LG	1870, 2212, 1453, 1693, 0208, 0067
	1335, 1872, 1798, 0744, 1667, 0636
	1751, 0586, 0745, 1964, 0728, 0736
	2087, 1889, 1179
Lifetec	0067, 0698, 1067, 1167, 0549, 2031
	0404, 0039, 0542, 0685, 0586, 0744
	0248, 0294, 1698, 0713, 1278
Loewe	0542, 0663, 1914, 0820, 0586, 0685
	0400, 0117, 0322, 0546
Logik	0041, 0063, 0223, 0401, 0910, 1247
	1067, 1717, 1675, 2271, 0067
Logix	0698, 1698, 0549
Luma	0067, 0393, 0236, 0193, 0441, 0586
	0404, 0039, 0289
Lumatron	0393, 2053, 0236, 2501, 0067, 0586
	0193, 0289, 0391, 0247, 0294, 0103
Luxman	0609
Luxor	0224, 0267, 0320, 0393, 0510, 0522
	0379, 0391, 0238, 0386, 0578, 0193
	0376, 0503, 0209, 1067, 0247, 0661
	1697
Madison	0067, 0586
Magnavox	0067, 0586



Magnum	0678, 0744, 0067, 0586, 0745, 1319 1586
Mandor	0294
Manesth	0067, 0586, 0265, 0247, 0294, 0350 0065, 0324, 0193, 0393
Manhattan	0067, 0586, 0698, 1067, 0193, 1698
Maqma	1328, 1732, 1739, 1636
Marantz	0067, 0586, 0442
Mark	0067, 0586, 0247, 0246, 0404, 0039 0744, 0745
Mascom	1586, 0586, 0067, 2155, 1615, 2227
Masuda	0401
Matsushita	0680
Maxim	2012, 1586
McMichael	0073
Mediator	0067, 0586, 0042
Medion	0744, 0838, 0067, 0549, 0698, 0586 0542, 2269, 1167, 0728, 0736, 1938 1067, 1467, 1930, 1278, 1698, 0275 0661, 1251, 0910, 1319, 1946, 1586 1179, 2031, 1697, 1879
Megas	0640
MEI	1067, 0067, 0586
Melectronic	0376, 0067, 0542, 0139, 0373, 0277 0135, 0134, 0404, 0039, 0247, 0510 0522, 0246, 0441, 0379, 0193, 0317 0586, 0654, 0664, 0391, 0221, 0225 0098, 0691, 0744, 1682
Memorex	0039
Memory	2013
Memphis	0367, 0102, 0039, 0415
Mercury	0067, 0039, 0586
Metz	1563, 0776, 0418, 0477, 0397, 0117 0225, 0565, 0584, 0221, 0067, 0586 0305, 0698, 1067, 1698, 1667
Micromaxx	0067, 0586, 0698, 1067, 0660, 0838 1698, 1354, 2031, 0744
Microstar	0838
Mikomi	1179
Minato	0067, 0586
Minerva	1278, 0517, 0565, 0225, 0100, 0221 0584, 0267, 0546, 0138
Minoka	0442, 0067, 0586, 0389
Mirai	1696, 1882, 2102, 1681
Mistral Electronics	0223
Mitsubishi	0138, 0542, 0067, 0117, 0063, 0066 0231, 0267, 0388, 0223, 0565, 0586 0721, 0238, 1964, 1067
Mitsuri General	0193
Monaco	0039
Morgan's	0067, 0586
MTC	0400, 0379, 0542, 0193, 0391, 0478
MTEC	0302
MTlogic	1338, 2134
Multimat	0462
Multitec	0067, 0586, 0516, 0698, 1067, 1586 1698, 2012

Multitech	0379,	0039,	0393,	0516,	0067,	0400
	0586,	0247,	0246,	0277,	0132,	0294
	0582					
Murphy	0134,	0246,	0102,	0193,	0231,	0381
Mx Onda	1717,	1675,	2171			
Myryad	0586,	0067				
NAD	0895					
Naiko	0067,	0636,	0586			
Nakimura	0404,	0067,	0586			
Naonis	0393,	0193				
National	0256					
NEC	0200,	0275,	1734,	1200,	0066,	0350
	0485,	0039,	0404,	0247,	0067,	0586
	0041,	0734,	0267,	0529,	0683,	0691
	2229					
Neckermann	0067,	0221,	0400,	1535,	1040,	0230
	0584,	0586,	0582,	0193,	0357,	0448
	0379,	0117,	0277,	0247,	0441,	0350
	0393,	0542				
NEI	0067,	0586,	0367,	0461,	0401,	0193
	1067					
NEO	0784,	1354				
Neovia	0895,	1406				
Nesco	0277,	0209,	0444,	1938		
Network	0367					
Neufunk	0067,	0039,	0586,	0640,	0248,	0312
	0744					
New Tech	0067,	0039,	0586,	0373,	0247,	0478
Nicamagic	0246					
Nikkei	0744					
Nobliko	0132,	0100,	0246			
Nokia	0391,	0193,	0510,	0379,	0578,	0522
	0389,	0503,	0381,	0369,	0238,	0404
	0616,	0661,	0636,	0376,	0209,	0350
	0640,	0139				
Nordic	0247					
Nordmende	0590,	0139,	2361,	0317,	2031,	0226
	0373,	0228,	0598,	0225,	0067,	0586
	0365,	0193,	0501,	1278,	0744,	1319
	1443,	0473,	2037,	1615,	1697,	1338
	0655					
Norfolk	0193					
Normerel	0067,	0586				
Novak	0042,	0067,	0586			
Novatronic	0067,	0135,	0404,	0586		
Novex	1553					
Novita	1615					
O.K.Line	1067,	1354,	1586			
Oceanic	0193,	0391,	0324,	0238,	0593,	0503
	0578,	0510,	2031			
Odeon	0294					
Odys	2269,	2271				
OKI	2155,	1697,	1615,	1338		
Olidata	1406					
Omega	0294					
Onwa	0401,	0248,	0463,	0611,	0132,	0461
Opera	1338,	0744,	1615			

Optoma	1784					
Orava	0582,	1067,	1179			
Orbit	0067,	0586				
Orion	2037,	2035,	0067,	0473,	0385,	0744
	0265,	2138,	0586,	0685,	0324,	0207
	0350,	0041,	0039,	0351,	0241,	0132
	0294,	0442,	0546,	0574,	1946,	1938
	0063,	0910,	1226,	2031,	1984,	1067
	1945					
Orline	0067,	0248,	0586			
Ormond	0415,	0698,	1067,	0067,	0586,	1698
Orsowe	0546					
Osio	0067,	0586,	0320			
Oso	0248					
Osume	0187,	0102,	0066,	0248,	0067,	0586
OTIC	1717,	1675,	2013			
Pace	1938					
Pacific	0067,	0586,	1167,	1267,	0744,	1067
	0473,	1354,	2037			
Pael	0246					
Palladium	0400,	0067,	0685,	0441,	0660,	0744
	1167,	0221,	1535,	1040,	0230,	0448
	0584,	0586,	0379,	0277,	0357,	0117
	0582,	0193,	0549,	0247,	0393,	2012
Panama	0039,	0247,	0294,	0246,	0067,	0586
	0277					
Panasonic	1666,	0680,	1680,	0256,	1340,	0304
	1240,	0244,	0391,	0883,	0267,	0880
	0397,	0546,	0067,	0586,	0193,	0578
	0381,	0138				
Papouw	0067,	0586				
Pathe Cinema	0193,	0268,	0246,	0350,	0322,	0379
	0461,	0582,	0400			
Pathe Marconi	0139,	0226,	0228,	0267,	0598	
Pausa	0039					
Perdio	0102,	0350,	0193,	0067,	0246,	0312
	0586					
Philco	0117,	0114,	0104,	0448,	0277,	0582
	0193,	0400,	0067,	0586,	0549	
Philex	0193,	0381				
Philharmonic	0247					
Philips	0586,	1536,	0067,	0669,	2045,	1613
	1525,	1897,	0802,	0043,	0042,	0584
	0073,	0117,	0223,	0453,	0373,	0404
	0039,	0230,	0391,	2244		
Phocus	1319,	1338,	0744,	1682		
Phoenix	0067,	0586,	0400,	0516,	0193,	0117
	0102,	0246,	0350,	0415,	0582	
Phonola	0067,	0586,	0042,	0043,	0117,	0223
	0246					
Pioneer	1290,	0790,	1487,	0196,	0709,	0067
	0586,	0453,	0458,	0373,	0391,	0139
	0193,	0317,	0516,	0542		
Pionier	0400,	0516				
Plantron	0067,	0586,	0294,	0039		
Playsonic	0744,	0067,	0247,	0369,	0745,	1682
Polar	0067					

Polaroid	1553, 1750, 1675, 1717, 2155
Policom	0598, 0132, 0139, 0226, 0228, 0236 0267, 0268, 0305, 0391, 0193, 0100 0104, 0114, 0117, 0565
Poppy	0039
Portland	0404, 0654, 1939
Powerpoint	0517, 0067, 0586, 0728, 0736, 1800
Prandoni-Prince	0277, 0546, 0391, 0393
Precision	0247
Prima	0039, 0294, 0333, 0098, 0442, 1226
Prinz	0102, 0574, 0379, 0391, 0224
Pro Vision	0529, 0067, 0586, 1067, 0744, 1354
Profex	0039, 0193, 0461, 0391, 0393
Profi	0039
Profilo	1586
Profitronic	0067, 0586, 0132
ProLine	0664, 1067, 0655, 0067, 0586, 0660 0441, 0042, 0351, 0102, 0651, 1406 2134, 2253, 2423
Prosonic	0067, 0586, 1769, 1895, 0400, 0404 0401, 0910, 0698, 1406, 0744, 2169 2171, 0481, 0246, 0244, 0609, 2031 0247, 1354, 1800, 1698, 1762, 2136 2120, 1739, 2275, 0636, 2227, 2130 2155, 1575, 1879, 0745, 1226, 1874 2080, 2051, 1553
Protech	0067, 0586, 0247, 0039, 0277, 0379 0132, 0294, 0461, 0448, 0367, 0698 0312, 0582, 0193, 0516, 1067, 1698
Proview	1717, 1675
Proxima	0765
Pye	0067, 0586, 0042, 0043, 0117, 0584 0404, 0379, 0442
Pymi	0039
Q.Media	2120
Quadro	0783, 1356, 0586, 0067, 0851, 1179 1697
Quasar	0277, 0895, 0039
Quelle	0067, 1535, 1040, 0041, 0139, 0542 0565, 0574, 0379, 0584, 0221, 0391 0066, 0247, 0277, 0104, 0357, 0114 0358, 0336, 0100, 0134, 0135, 0698 0586, 0187, 0225, 0230, 0294, 0320 0176, 1067, 0324, 0376, 0451, 0582 0039, 1698
Questa	0066
Radiola	0067, 0586, 0042, 0247
Radiomarelli	0117, 0231, 0546, 0277, 0067, 0586
Radionette	0744
RadioShack	0067, 0586
Radiotone	0039, 0067, 0586, 0458, 0400, 0609 0448, 0442, 0678, 0698, 0294, 1067 1698
Rank	0100
Rank Arena	0066, 0187
RBM	0100, 0119
Recor	0067, 0586

Rectiligne	0067, 0586
Red Star	0067, 0586
Rediffusion	0231, 0391, 0381, 0578, 0066, 0376
Reflex	0067, 0586, 1067, 0698, 1698
Relisys	1769, 0895, 1328, 1406, 1615, 1675
Revox	0067, 0586, 0400
Rex	0236, 0393, 0441, 0277, 0193, 0289 0294
Ricoh	0067, 0586
Roadstar	1067, 0745, 0039, 0448, 0067, 0586 0744, 0698, 0248, 0294, 0312, 1946 1698, 1930, 1356, 2171
Robotron	0117
Rolsen	0067, 0586, 2067, 2031
Rowa	0294, 0247, 0039, 0246, 0617, 0067 0586
Roxy	0478
Royal Lux	0451, 0400, 0442, 0365
Rukopir	0586, 0067
Saba	0655, 0139, 0590, 0373, 0317, 0117 0193, 0546, 0391, 0528, 0226, 0228 0365, 0598, 0578, 0501, 0680, 0744 1618
Saccs	0268
Saga	2227
Sagem	0640, 0485, 0312, 0860, 0648
Saivod	0067, 0586, 0698, 0742, 1067, 1698
Sakaï	0193
Salora	0320, 0224, 0379, 0193, 0386, 0389 0391, 0546, 0393, 0578, 0369, 0238 0582, 0510, 0651, 1267, 0661, 1586 2184, 2155, 2227, 2031
Salsa	0365
Sambers	0546, 0132
Samsung	0842, 0648, 0617, 1488, 0586, 1279 0674, 1265, 0039, 0067, 0247, 0478 0512, 0400, 0090, 0796, 0844, 1937 0102, 0294, 0712, 0246, 0320, 0549 0193, 0748, 0208
Sandra	0246, 0247
Sanela	0268
Sansui	0067, 0586, 0401, 1965
Santon	0039
Sanyo	0238, 1238, 0187, 0322, 0066, 0041 0400, 0369, 0102, 0246, 0247, 0134 0075, 0585, 0176, 0039, 0574, 0193 0067, 0327, 0586, 0516, 0765, 0200 0734, 1679, 1067, 1697, 1179, 1615
Save	0067, 0586
Saville	1938
SBR	0067, 0586, 0042, 0223, 0043, 0073
Schaub Lorenz	0578, 0744, 0391, 0379, 0636, 0516 0404, 1354, 1393, 2130, 1697, 2155 1338
Schneider	1167, 0067, 0586, 0549, 0042, 0333 0574, 0379, 0424, 0382, 0289, 0373 0247, 0277, 0401, 0391, 0248, 0698

	1067, 0193, 0678, 0744, 0043, 0654
	1939, 1938, 1698, 2012, 1946, 0100
	1647, 1354, 1267
Scotland	0193
Scott	2013
Sears	0176
Seaway	0664
SEG	1067, 0067, 0586, 1467, 0698, 0247
	0517, 0039, 0379, 0193, 0294, 0327
	0664, 0066, 0132, 0277, 0444, 0246
	0582, 0248, 1939, 0654, 1698, 1179
	2155, 1553, 1615
SEI	0117, 0132, 1535, 1040, 0582, 0193
	0546, 0574, 0379, 0324, 0236, 0067
	0586, 0207
Sei-Sinudyne	0132, 0236, 0324, 0546, 1535, 1040
	0582, 0574, 0067, 0586, 0117
Seleco	0236, 0393, 0289, 0193, 0441, 0401
	0066, 0294, 0376, 0465, 0660
Sencor	0744, 2269, 2227
Sencora	0039
Sense	1879
Sentra	0065, 0248, 0039, 0379
Sharp	0123, 1223, 1423, 1123, 2244, 0187
	0066, 1849, 0324, 0286, 0223, 0546
	0230, 1965
Shinelco	2134, 2271
Shintoshi	0067, 0586
Shivaki	0067, 0586, 0473, 2037, 0481, 0404
	0208
Siarem	0582, 0193, 0117, 0132, 0546
Siemens	0221, 0565, 0584, 0230, 0225, 0357
	0358, 0187, 0176, 0067, 0586, 0391
Siera	0067, 0586, 0042, 0617
Siesta	0400
Silva	0067, 0586, 0246, 0391, 0678
Silva Schneider	0783
Silver	0066, 0391, 0209, 0745, 0193
SilverCrest	1067, 0067, 0586
Simz	2171
Singer	0039, 0117, 0067, 0586, 0132, 0277
	0465, 0365, 0193
Sinudyne	1354, 0207, 0117, 0265, 0132, 0324
	0582, 0193, 0391, 0546, 0574, 0379
	1535, 1040, 0236, 0067, 0586, 1938
	0636
Skantic	0386
Sky Media	1644, 1643, 1636, 1805, 1739, 0691
	0895
Skymaster	0135
Sliding	0895, 0910, 1354
Smaragd	0517
Sogera	0350
Sogo	1406
Solavox	0391, 0102, 0193, 0578, 0381, 0067
	0586
Sonawa	0248

Soniko	0067, 0586
Sonitron	0238, 0400, 0369, 0247
Sonoko	0067, 0586, 0039, 0294, 0312, 0247
Sontec	0067, 0586, 0400, 0324, 0039
Sontech	2013
Sony	1855, 1535, 1681, 1581, 1040, 0041 0383, 0066, 0132, 0187
Sound & Vision	0132, 0248, 0404, 0067, 0586
Soundwave	0067, 0586, 0350, 0448, 0745
Standard	0067, 0586, 1067, 0248, 0039, 0247 0350, 0404, 1739
Starlite	0039, 0582, 0193, 0067, 0586, 0294 0442
Stenway	0312, 0248
Stern	0236, 0289, 0193, 0393, 0294, 0441 0465
Stevison	2012, 1586
Strato	0067, 0586, 0294, 0039
Strong	1179, 1067, 0067, 0586
Stylandia	0247
Sungoo	2067
Sunic Line	0067, 0586
Sunstar	0401, 0067, 0586, 0039, 0609, 0294
Sunstech	2031
Sunwood	0067, 0586, 0039
Superla	0546, 0246, 0247
SuperTech	0039, 0067, 0586, 0246, 0248
Superton	0461
Supra	0404, 0039
Susumu	0365, 0248, 0317
Sutron	0039
Swedx	1636
Sydney	0246, 0247
Sysline	0067, 0586
Sytong	0246
T+A	0477
Tandberg	0397, 0441, 0139, 0367, 0226, 0391 0193
Tandy	0248, 0102, 0247, 0277, 0123, 0193 0444
Targa	0648, 2275
Tatung	1750, 0651, 0067, 1278, 1586, 0586 0102, 0546, 0247, 0302, 0279, 0041 0274, 0659, 0079, 0063, 1938, 1749 1354, 1946
Taurus	2227
TCM	0744, 1319, 0838, 2031, 1338
Teac	2198
TEC	0247, 0039, 0277, 0501, 0365, 0367 0289, 0582, 0067, 0586, 0391, 0193
Tech Line	0067, 0586, 0698, 1467, 1698
Technica	2012, 0651
TechniSat	0685, 0327, 0067, 0586, 0193, 2452
Techno	1615, 1067
Technol Ace	0209
Techvision	1739
Techwood	1067, 1697

Teckton	1406					
Teco	1553					
Tedalex	0247, 0636, 0067, 0039, 0238, 0617					
	0586, 0461					
Telefunken	0655, 0590, 0104, 0139, 0373, 0528					
	0292, 0501, 0317, 0114, 0131, 0365					
	0336, 0103, 0226, 0067, 0586, 0516					
	0598, 0744, 1586, 0376, 0851, 1615					
	1618					
Telefusion	0067, 0586					
Telemeister	0350, 0067, 0586					
Telesonic	0067, 0586					
Telestar	0067, 0586, 0609, 0442					
Teletech	0067, 0586, 0698, 0039, 0277, 0367					
	0444, 1067, 1698					
Teleton	0247, 0305, 0236, 0193, 0379, 0289					
	0066, 0393					
Televideon	0350, 0582, 0193, 0246					
Television	0067, 0586					
Telexa	0132					
Tensai	0134, 0248, 0067, 0586, 0247, 0324					
	0350, 0039, 0135, 0404, 0401, 0407					
	0277, 0745, 0193, 1067					
Tenson	0350, 0039					
Tesla	1067, 0067, 0698, 0744, 1682, 0745					
	1167, 0660, 0401, 0726, 0549, 0783					
	0586, 0268, 0640					
Tevion	1278, 1586, 0838, 0895, 1717, 2271					
	1615, 0744, 2120, 0067, 2227					
Texet	0247, 0404, 0039, 0246, 0248					
Thomas	1934					
Thomson	0655, 0590, 0373, 0317, 0139, 0501					
	0365, 0226, 1618, 0228, 0267, 0067					
	0586, 0598, 0350, 0379, 0246, 0582					
Thorn	0138, 0139, 0255, 0373, 0391, 1535					
	1040, 0565, 0102, 0041, 0042, 0043					
	0063, 0066, 0073, 0075, 0100, 0131					
	0386					
Thorn-Ferguson	0134, 0220, 0222, 0223, 0365, 0065					
Tokyo	0246, 0065, 0478, 0333					
Topline	1067, 0698					
Toshiba	1538, 0538, 0065, 0583, 1319, 0744					
	1697, 0119, 0273, 0748, 1965, 0100					
	0132, 0271, 1612, 1734, 0247, 0225					
	0221, 0648, 1946, 1938, 0039, 0067					
	1586, 0680, 1067, 1682, 0770					
Towada	0379, 0132, 0247, 0582					
Toyoda	0039					
Trakton	0294					
Triad	0067, 0586, 0248, 0039					
Trical	0187					
Trident	0546, 0247					
Trio	1717, 1675					
Tristar	0294, 0248, 0223					
TVTEXT 95	0586					
Uher	0067, 0586, 0236, 0350, 0333, 0404					
	0448, 0516, 0400, 0289, 0510					



Ultravox	0117, 0132, 0404, 0277, 0246, 0582
	0193, 0067, 0586, 0381
Unic Line	0067, 0586, 0503, 0485, 0379
United	0744, 2013, 0067, 0745, 0586, 1946
	1938, 1067, 0617, 2012, 1682, 2171
	1800, 1553, 2155
Univox	0067, 0586, 0367, 0117, 0193, 0268
Utax	0193
V2M	0684
V7 Videoseven	0208, 0910, 1406, 1247, 1696, 0648
	1681, 1535
Venus	1356
Vestel	1067, 1615, 1697, 0067, 0698, 0582
	0193, 0247, 0586, 1698
Vexa	0039, 0067, 0586
Vibrant	0302
Videocon	2361
Videologic	0248, 0246
VideoSystem	0067, 0586
Videoton	0386, 0193, 0461
Vidikron	0132, 0765
ViewSonic	1572, 1618, 2141
Viper	0367
Visiola	0246
Vision	0067, 0586, 0350, 0247
Visorex	0462
Vistar	0236, 0391
Vivax	1356, 1338, 1647, 1732, 0067, 1739
Vortec	0067, 0586
Voxson	0117, 0067, 0586, 0393, 0448, 0193
	0208, 2227, 0684
Waltham	0247, 0386, 0448, 0317, 0415, 0067
	0586, 0698, 0139, 1067, 0461, 1698
	0193, 0473, 2037
Wards	0209
Watson	1067, 1278, 0350, 0586, 0067, 0193
	0039, 0698, 0248, 0609, 0549, 0424
	0684, 1938, 1467, 1698, 1406, 0357
Watt Radio	0132, 0574, 0379, 0582, 0193, 0246
	0516, 0458
Wega	0067, 0586, 0066, 0117
Wegavox	0039, 0067, 0586
Welltech	1682
Weltblick	0067, 0586, 0350, 0247
Weltstar	1067
Weston	0067, 0586
White Westinghouse	0350, 0246, 0067, 0586, 0367, 0654
	1939
Wilson	0586
Windstar	0312, 0367
Windy Sam	0586
Xiron	2013
Xrypton	0067, 0586
Yamaha	0680, 0827, 1606
Yokan	0067, 0586
Yoko	0247, 0067, 0586, 0248, 0294, 0039
	0461, 0451, 0400, 0369, 0246, 0277

Yorx  
Zanussi  
Zepto

0248  
0236, 0393, 0247  
1615