

I/O-lista  
Pneumatiktavlor

<b>Benämning</b>	<b>Styrsystem</b>	<b>Styrsystem</b>	<b>Styrsystem</b>
<b>Pneumatikstation</b>	<b>SIEMENS S7</b>	<b>FX1-S</b>	<b>ALPHA</b>
S3, C1-	I 124.0	X 2	IN 6
S4, C1+	I 124.1	X 3	IN 7
S5, C2-	I 124.2	X 4	IN 8
S6, C2+	I 124.3	X 5	IN 9
S7, C3-	I 124.4	X 6	IN 10
S8, C3+	I 124.5	X 7	IN 11
S9, C4-	I 124.6	X 10	IN 12
S10, C4+	I 124.7	X 11	IN 13
S11, Pa		X 12	IN 14
-----			
Y1 Ventil C1 5/2	Q 124.0	Y 0	OUT 1
Y2 Ventil C2 5/2	Q 124.1	Y 1	OUT 2
Y3 Ventil C3 5/2	Q 124.2	Y 2	OUT 3
Y4 Ventil C4 5/2	Q 124.3	Y 3	OUT 4
Y5 Ventil 3/2	Q 124.4	Y 4	OUT 5
Y6 Ventil 3/2	Q 124.5		
Y7 Ventil Vacc		Y 5	OUT 6

**Manöverpanel Siemens**

Tumhjul b0	I 125.0
Tumhjul b1	I 125.1
Tumhjul b2	I 125.2
Tumhjul b3	I 125.3
Vippomk S20	I 125.4
Vippomk S21	I 125.5
Tryckknapp S24	I 125.6
Tryckknapp S25	I 125.7

24VDC Matning MP Q 124.7

7-segm. b0	Q 125.0
7-segm. b1	Q 125.1
7-segm. b2	Q 125.2
7-segm. b3	Q 125.3
Diodlampa H20	Q 125.4
Diodlampa H21	Q 125.5
Diodlampa H22	Q 125.6
Diodlampa H23	Q 125.7

